



# Ultimaker 2, 2Go - Adaptor Setup

How to install the 1.75mm Adaptor (B) with Ultimaker 2 and Ultimaker 2Go.

Written By: Adalyn Ordone



## INTRODUCTION

This installation uses the [1.75mm Adaptor B](#)

## Step 1 — Bowden Tube Replacement



- [Replace bowden tube](#)

## Step 2 — Install the Palette tube into the extruder input



- [Install PTFE into the extruder.](#)

### Step 3 — Installing the short hot-end PTFE sleeve into the hot-end



- [Installing the PTFE tube into the hot end.](#)

### Step 4 — 1.75mm single color test print



- [Single color printing test.](#)

## Step 5 — Palette Calibration



- [Continue with calibrating Palette 2 with your Ultimaker 2 or 2Go.](#)